

Example of a starting Serial # RT4060210000001			
RT4	06	0210	000001
Model #	Plant #	Year/month	Serial Number
Operation Manual REX2289			
Service Manual M051-00K25-A059			
Transformer 120/60 REX01HR			


LEFT PEDAL
REX21N1
CRANK CAP
REX01A8
LEFT CRANK ARM
REX01A9
WASHER
REX0JZM
CRANK COVER
REX20F9
SCREW
REX0KDK
SCREW
REX0KDJ
LEFT SIDE COVER
REX20F5
RIGHT SIDE COVER
REX20EX
RIGHT CRANK ARM
REX01AA
WASHER
REX0JZM
CRANK COVER
REX20F9
CRANK CAP
REX01A8
RIGHT PEDAL
REX21N2
COVER PLATE
REX20FA
SCREW
REX0KDK
LABEL
REX21SH
LABEL
REX21ST

CONSOLE ASSEMBLY (ENG/ENG)
REX22D8




SEAT BACK
REX20PX
SEAT BOTTOM
REX247Y
HANDLE BAR
REX20NTG
SCREW
REX0K03
WASHER
REX0J5G
END CAP
REX20TY
WASHER
REX0J95
FOAM
REX20NF
SCREW
REX118N
END CAP
REX01CZ
PLUNGER HOUSING
REX20MR
HANDLE SHAFT
REX20MS
E-RING
REX20Z6
SEAT FRAME
REX20MT
HANDLE
REX20MJ
WASHER
REX0J95
PIN
REX20MQ
RUBBER WASHER
REX20ML
SCREW
REX118N
WASHER
REX213D
SPRING
REX20MP
SCREW
REX0K77
BLOCK
REX20MN
REX22LD
LOCKING MECHANISM ASSY
SCREW
REX0KAA
PIN REX20MK


SEAT SCALE
REX21SE
TRACK
REX20ME
WASHER
REX0J5G
SCREW
REX0K0B
COLLAR STOP
REX01VL
WASHER
REX0J5G
PLATE
REX20MD
0J53
WASHER
REX0J5G
SPACER
REX21RA
COLLAR
REX01VM
SCREW
REX0K0C
SCREW
REX0K5C
SCREW
REX0K0B
STOP
REX21NY
SCREW
REX0K06


C-RING
REX20ZA
ADJUST WHEEL
REX20PZ
WASHER
REX213C
TENSION AXLE
REX20PY
BOLT
REX20W1
SPACER
REX20Q2
WASHER
REX0J93
WASHER
REX213E
ROLLER
REX20Q1
PLATE
REX0KQZ
NUT
REX20W0
SPACER
REX20Q0


D.C. MOTOR
REX01HL
LOWER MAIN WIRE HARNESS
REX20Y8
BRAKE LEADWIRE
REX20TD
REED SWITCH
REX21SY
CRANK SHAFT
REX20LB
BEARING
REX0HVQ
DRIVE PULLEY
REX20L2
WHEEL
REX01AK
REAR COVER
REX20FK
SPRING
REX01QU
BELT R
EX21RF
MAG BRAKE
REX20EK
BRACKET RIGHT
REX20LL
REAR STABILIZER
REX215Q
BEARING
REX0HVP
END CAP
REX20N7
BRACKET LEFT
REX20KZ
IDLER BRACKET
REX20NU


SCREW
REX0K4A
BOLT
REX0WRG
WASHER
REX09FP
BOLT
REX0JPT
SCREW
REX0K3G
KEY
REX0JGM
C-CLIP
REX0JEJ
MAGNET
REX01H5
INSERT NUT
REX21QY
SCREW
REX0K4R
NUT
REX0KMS
WASHER
REX0J4J
NUT
REXOKN5
SCREW
REX21RE
INSERT NUT
REX21RG
SCREW
REX0K01
SCREW
REX0K2B
SET PLATE
REX21PX
SLEEVE
REX20M0
SPACER
REX019S
WASHER
REXOJ4E
BOLT
REXOJQB
NUT
REX0KMW
INSERT NUT
REX21QY
SPRING
REX0J93
NUT
REX20W4
SCREW
REX0JZU
LEVELER
REX215P